

Installation Instructions for FM10



Place the Quick Fist Longarm onto the mount as shown and insert M6 bolts into washers and into the mount.



Secure with the small washers and nuts.

Note: A thread lock compound such as Loctite is a fantastic idea here.



Place the supplied large bolt into the mount, then place 3 washers and the large nut onto the back side as shown. The nut does not thread onto the bolt, it is just being used as a spacer.

Remove the rear seat belt and secure the mount to the D pillar.

If you are missing anything please email RefinedCycle@gmail.com.

