

Installation Instructions for FM12

WARNING!: NOT intended to be used with a passenger in the back seat. It hangs low enough to present a possible hazard when entering or exiting and in an accident! Please use caution and common sense.



To remove the rear grab handle, pry out both square plastic screw covers with a small screwdriver.



Remove both screws to remove the handle.



Place a washer onto each of the bolts.



Place the short bolt into the end of the mount with the round hole (not the slotted end) and place the short spacer onto the back side.



Loosely attach the mount to the hole toward the front of the truck. It is helpful to push the trim against the ceiling to get the bolt started.



Place the longer spacer into the ceiling and rotate the mount up and line up the slot, the spacer and the screw hole in the ceiling.



Thread the longer bolt into the hole and tighten both bolts.



Put washers onto the 4 small screws.



Attach the fire extinguisher bracket to the mount with the small screws. Put the curved end of the fire extinguisher bracket (that holds the nozzle end) toward the back of the truck. Note: A thread lock compound such as Loctite is a fantastic idea here.

Install the extinguisher into the bracket. It is highly recommended to use a Velcro strap to secondarily secure the extinguisher.

If you are missing anything please email RefinedCycle@gmail.com.