

Installation Instructions for FM13



Note: You can mount the Quick Fists with the straps pointing up or down, just make sure when you install the mount, the edge of the Quick Fist that is flush with the edge of the mount is toward the floor.

Insert small screws into the countersunk hole in the black plastic square washers.

Insert that into the Quick Fists and secure with the small washers and nuts. A thread lock compound such as Loctite is a fantastic idea here.



Move the seat all of the way back to access the seats front bolts and remove the plastic cover over the bolts, then remove the bolts.

Place the spacers under the mount and secure with the new bolts.



Attach flashlight

If you are missing anything please email RefinedCycle@gmail.com.