

## Installation Instructions for FM2



Attach the fire extinguisher bracket to the mount with the supplied small screws, washers and nuts. Depending on which side you are installing the mount on, put the curved end of the fire extinguisher bracket (that holds the sprayer end) toward the CENTER of the vehicle.

Note: A thread lock compound such as Loctite is a fantastic idea here.



Move the seat all of the way back to access the seats front bolts and remove them.

Place the spacers under the mount and secure with the large bolts and washers as shown.



If you have floor mats you may need to trim as shown with the marked lines. Also you will need to add a few washers on top of the spacer to raise the mount another 1/4" to clear the floor mat clips.

If you are missing anything please email [RefinedCycle@gmail.com](mailto:RefinedCycle@gmail.com).