

## Installation Instructions for FM6



To remove the handle, pry out the square plastic screw covers with a small screwdriver and remove the screws.



Insert the supplied long screws into the washers, then into the end holes of the mount.



Place a nut onto the back side. These do not thread on, they are just being used as a spacer.



Attach the mount to the existing holes in the ceiling. Align the mount so that the LARGE hole in the center of the mount is more toward the FRONT of the vehicle.



Use the other washers and small screws to attach the fire extinguisher bracket to the mount as shown.

Note: A thread lock compound such as Loctite is a fantastic idea here.

If you are missing anything please email [RefinedCycle@gmail.com](mailto:RefinedCycle@gmail.com).