

Installation Instructions for FM8



Place the supplied large bolt into the mount, then place 3 washers and the large nut onto the back side as shown. The nut does not thread onto the bolt, it is just being used as a spacer.



Remove the rear seat belt and secure the mount to the D pillar.



Place the supplied washers onto the small screws and into the fire extinguisher bracket as shown.



Using the other nuts supplied as spacers on the 4 screws as shown, attach the fire extinguisher bracket with the curved end up.

Note: A thread lock compound such as Loctite is a fantastic idea here.

If you are missing anything please email RefinedCycle@gmail.com.