

Installation instructions for RR2 and RR3 Replacement Rock Rings for Toyota TRD "Beadlock" Wheels

Please read these instructions entirely before starting. This picture shows the components of the RR2 and RR3. Parts will be referred to by the names & numbers shown here. If you are missing anything please email RefinedCycle@gmail.com.



Components

1. Rock Ring Sections (Qty. 4 per wheel)
2. M8-1.0x16 Hex Head Bolt (Qty. 12 per wheel)
3. Zinc Washer (Qty. 12 per wheel)
4. Nylon Washer (Qty. 24 per wheel)



Use one Zinc Washer on each M8 Bolt and apply Blue Loctite to the bolt.



Insert the Bolt into the front of a section.



Place two Nylon Washers onto the back side.



Start all of the bolts, then tighten the shared holes first so that you can adjust the gaps evenly and line up the two ends evenly, then tighten the rest of the bolts.

Important: Do not over tighten the bolts. About 5-6 lb./sq. in. torque is sufficient. You do not want to strip the aluminum holes in your wheels.

When you trail damage a section just flip that section over and continue use!

Now hit the trails!